

## Quick Start Guide MULTIMEDIA NAVIGATION RECEIVER AVIC-8000NEX/AVIC-7000NEX


This guide is intended to guide you through the basic functions of this navigation system. For details, please refer to the Operation Manual provided with the product.

### Basic hardware buttons




- ① **VOL (+/-) button**  
Press to adjust the AV (Audio and Video) source volume.
- ② **MAP button**  
Press to display the Map screen.
- ③ **HOME button**  
Press to display the Top menu screen.
- ④ **MODE button**  
Press to switch between the Application screen and the AV operation screen.
- ⑤ **TRK button**
- ⑥ **▲ button**

### Switching screens using the touch panel keys




### Switching screens using the hardware buttons



### How to use the navigation menu screens


You can use various functions such as the route guidance and related settings.  
You can see some of menu options when you are navigating without a planned route.



- ① Returns to the Map screen.
- ② Searches for your destination by entering an address, its coordinate, or selecting a place of interest, etc.
- ③ Builds your route using the list of destinations.
- ④ Displays useful information to support your driving.
- ⑤ Configures the program settings.
- ⑥ Sees notifications that contain important information for the users.
- ⑦ Displays the **"User Profile"** screen where you can create new profiles or edit the existing profiles.
- ⑧ Mutes the sound of the navigation system (the voice guidance, or beep sounds, for example).
- ⑨ Switches among 2D, 3D, or 2D North up view modes.
- ⑩ Displays the location where you saved as a favorite.
- ⑪ Displays the information of your navigation system (the version information, or licenses, for example).


### Searching for a location by address

- 1 **Press the MAP button.**  
The Map screen appears.
- 2 **Touch [Menu] to display the navigation menu on the Map screen.**
- 3 **Touch [New Route].**
- 4 **Touch [Address].**  
The **"Find Address"** screen appears.




- 5 **Touch [Country], and select the country.**
- 6 **Touch [Town], and select the city/town.**
- 7 **Touch [Street], and select the street.**
- 8 **Touch [House Number / Intersection], and select the house number or the crossing street.**  
After you touch the selected address to finish the address search, the searched location appears on the Map screen.

- 9 **Touch [Select as Destination].**



After a short summary of the route parameters, a map appears showing the entire route. The route is automatically calculated.


- 10 **Touch [Start Navigation].**



Your navigation system starts the route guidance.

## How to use the map

Most of the information provided by your navigation system can be seen on the map. You need to become familiar with how the information appears on the map. Information with an asterisk (\*) appears only when the route is set. The AV information is displayed in the bottom of the Map screen.




- ① Shows the number and name of the street to be used (or next guidance point).\*
- ② Shows the next guidance point (maneuver).\*
- ③ Shows the distance to the next guidance point (maneuver).\*
- ④ Shows the second maneuver arrow.\*
- ⑤ Indicates the current location of your vehicle.
- ⑥ Displays the following information.\*
- The estimated time of the arrival at the destination
- The remaining time of the trip
- The remaining distance to the destination
- ⑦ Shows the name of the street (or city) that your vehicle is traveling on (or in).
- ⑧ Indicates the current route.\*
- ⑨ Displays the Navigation menu screen.
- ⑩ Indicates the progress to the final destination.\*

## Pairing your Bluetooth® devices

You can use various additional functions (hands-free phoning and Bluetooth audio) by connecting your Bluetooth devices to this navigation system. To use the functions, pair the devices with the navigation system in advance.


- 1 **Activate the Bluetooth wireless technology on your devices.**
- 2 **Press the HOME button to display the Top menu screen.**
- 3 **Touch [Settings] then [Bluetooth].**  
The "Bluetooth" screen appears.
- 4 **Touch [Connection].**
- 5 **Touch [Search].**



- 6 **Touch the Bluetooth device name you want to register.**  
While connecting, "Pairing... Please wait." is displayed. If the connection is established, "Paired." is displayed.

## Using hands-free phoning


If your cellular phone features Bluetooth technology, this navigation system can be connected to your cellular phone wirelessly. Using this hands-free function, you can operate the navigation system to make or receive phone calls. You can also transfer the phone book data stored in your cellular phone to the navigation system.



- ① Displays the preset dial screen.
- ② Switches to the phone book list.
- ③ Switches to the missed, received and dialed call lists.
- ④ Switches the mode to enter the phone number directly.
- ⑤ Switches to the voice recognition function (for iPhone).
- ⑥ Displays the Setting menu screen.
- ⑦ Closes the screen.
- ⑧ Displays the alphabet search screen.

## Using the radio

You can listen to the radio using this product. Once you have stored broadcast channels from memory, you can easily recall preset channels from memory with a single touch of a key.



- ① Displays the source list.
- ② Selects a band.
- ③ Displays the Time and date setting screen.
- ④ Displays the Setting menu screen.
- ⑤ Recalls equalizer curves.
- ⑥ Switches the text display between the main channel and sub channels.
- ⑦ Displays the Phone menu screen.
- ⑧ Stores song information to an iPod.
- ⑨ Performs manual tuning or seek tuning.
- ⑩ Displays the preset channels.
- ⑪ Recalls the preset channel stored to a key from memory with a single touch of the key. Stores the current broadcast frequency to a key for later recall by continuing to touch the key.